L-28-3D (Sercel) is wired in the following manner:

Axis	Signal Response	U77/U
VERTICAL, Channel 1	Tap Down	А
	(positive signal on scope) Tap Up	
		В
	(negative signal on scope)	D
NORTH-SOUTH, Channel 2	Tap North	с
	(positive signal on scope)	
	Tap South	
	(negative signal on scope)	D
EAST-WEST, Channel 3	Tap East	
	(positive signal on scope)	E
	Tap West	
	(negative signal on scope)	F



U77/U Connector

v.20081007

Orientation:

The L-28 sensor should be oriented with the arrows on the top of the case pointing North and East.

